



Installing your Edge Deceleration System

IMPORTANT NOTE ABOUT STOP BLOCKS

SAFETY WARNING: ALWAYS use a **SOLID** ground mount (i.e. a tree) to attach the shock cord to. Failure to use a solid mount has the potential to cause the stop block to fail or to snap back towards the rider causing serious injury or death. If you are unsure of what constitutes a solid mount, consult a local contractor for assistance.

Tools Needed: 3/16" Allen wrench, 1/2" wrench



Remove the trolley from box.



Loosen the top two wheels.



Put the unit onto your zip line, with the white bumper facing the upper tree.



Insert the screw into the appropriate hole for your cable size, and the nylon washer between the red frames.



Insert the wheel and 2nd nylon washer between the red frames. Secure with the nut.



Tighten all three wheels.



Find these parts.



Place one washer on the clevis pin and thread through the red frames and d ring as shown.



Place the 2nd washer on and insert the cotter pin, bending one side down.



Finally, attach the end of your shock cord to a solid mount adjacent to your line.