

Installing Your Slack Line Kit to Your Tree



1. Take the slack line components out of your box.



2. Remove the banding with scissors.



3. Install the tree saver felt pad and ratchet strap sling as shown. Make sure your line is no higher than 20 inches from the ground.



4. Install the slack line and tree saver felt pad around the other tree as shown.



5. Unroll the line making sure the design is facing up.



6. Open the ratchet and feed the line up and through the ratchet and back down.



7. Pull the line through the ratchet.



8. Using the ratchet, tighten the line to your desired tension.



9. Close the ratchet, making sure it locks in place.



10. The final result should look like this.